

# Instructions: Folding Camping Trailer Cover

## CAUTION

Please consult your RV owners manual.

## Installation

1. Fold your camping trailer down and secure it. Cover or tape any sharp edges on your trailer that could wear against your cover.
2. Find the Classic logo on your cover – this is the front. Slip your Folding Camping Trailer Cover over the top of your trailer then pull the elasticized bottom hem down along the bottom edge of the trailer.
3. Using the supplied rope, tie into a loop on the bottom edge of the cover. Run the rope underneath your trailer and tie into the opposite loop. Repeat with the remaining loops. Adjust as necessary to fit your particular trailer.

## Use and Storage

A handy storage bag is provided. To fit your cover in the bag fold and roll it tightly rather than stuffing it. Never store a wet cover in the storage bag or confined area as the cover can be damaged by mildew.

## Care

Spot clean with water, a mild soap and a sponge. Don't use abrasive cleaners or brushes.

## Two Year Limited Warranty

If this cover fails due to a defect in workmanship and materials within two years from the date of purchase, Classic Accessories will repair or replace it free of charge.

Trailing or towing with your Folding Camping Trailer Cover on will invalidate the warranty.



This warranty gives you specific rights and you may also have other rights which vary from state to state.



Classic Accessories, Inc.  
Kent, WA, USA 98032  
www.classicaccessories.com

74203 74303 74403 74503 74603 09cR55\_11169

# Instructions: Folding Camping Trailer Cover

## CAUTION

Please consult your RV owners manual.

## Installation

1. Fold your camping trailer down and secure it. Cover or tape any sharp edges on your trailer that could wear against your cover.
2. Find the Classic logo on your cover – this is the front. Slip your Folding Camping Trailer Cover over the top of your trailer then pull the elasticized bottom hem down along the bottom edge of the trailer.
3. Using the supplied rope, tie into a loop on the bottom edge of the cover. Run the rope underneath your trailer and tie into the opposite loop. Repeat with the remaining loops. Adjust as necessary to fit your particular trailer.

## Use and Storage

A handy storage bag is provided. To fit your cover in the bag fold and roll it tightly rather than stuffing it. Never store a wet cover in the storage bag or confined area as the cover can be damaged by mildew.

## Care

Spot clean with water, a mild soap and a sponge. Don't use abrasive cleaners or brushes.

## Two Year Limited Warranty

If this cover fails due to a defect in workmanship and materials within two years from the date of purchase, Classic Accessories will repair or replace it free of charge.

Trailing or towing with your Folding Camping Trailer Cover on will invalidate the warranty.



This warranty gives you specific rights and you may also have other rights which vary from state to state.



Classic Accessories, Inc.  
Kent, WA, USA 98032  
www.classicaccessories.com

74203 74303 74403 74503 74603 09cR55\_11169